


USER'S MANUAL

VIDEO SYSTEM ON PLASTIC OPTICAL FIBER

FP-TRX150/ FP-TRX300



REFERENCE FIGURES - FP-TXRX150

A – Power inlet

B – Signalization LED (the unit is on), the power supply is present

C – Video signal output (BNC)



D – Optical signal input (F-SMA)

E – Gain regulation

F – Optical signal output (F-SMA)

G – Electric signal input (BNC)

H – Label with serial number

REFERENCE FIGURES - FP-TXRX300

- A – Power inlet
- B – LED signaling that the power supply is present
- C - LED signaling the connection quality
- D – Video signal output (BNC)
- E – Optical signal input (F-SMA)
- F – Optical signal output (F-SMA)
- G – Video signal input (BNC)
- H – Label with serial number

THE ADVANTAGES OF THE PLASTIC OPTICAL FIBER

This Video System works with plastic optical fiber (POF). The use of the plastic fiber guarantees the following:

- 1) the transmission of analog video signals up to 300 m away (FP-TRX300) and up to 150 m away (FP-TRX150);
- 2) easy and fast installation without specific tools;
- 3) complete immunity to electromagnetic disturbances and no electromagnetic emissions;
- 4) complete immunity to ground loops;
- 5) high resistance to weather conditions, dust, oils and mechanical stresses;
- 6) existing raceways containing electric cables can be used.

TECHNICAL SPECIFICATIONS - FP-TXRX150

Manufacturer	Made in Italy
Degree of protection	IP20
Image standard	PAL / SECAM / NTSC (1 Vpp)
Transmitted band	0 ~ 5.5 MHz
Transmission distance (m)	10 ~ 150
Gain regulation	Manual
Power supply	+12V CC stabilized (feeder not supplied)
Consumption (mA)	80 max (Tx) / 50 max (Rx)
Weight (g)	50 (Tx) e 70 max (Rx)
Dimensions (mm)	44.60x29.40x26.90 (Tx) / 65.7x27.5x25.8 (Rx)
Optical output connector	F-SMA
Electric input connector	BNC 75Ω
Storage temperature (°C)	-30 ~ +70
Operating temperature (°C)	-20 ~ +60
Immune to electromagnetic interferences	Yes

TECHNICAL SPECIFICATIONS - FP-TXRX300

Manufacturer	Made in Italy
Degree of protection	IP20
Image standard	PAL / SECAM / NTSC (1 Vpp)
Transmitted band	0 ~ 6.0 MHz
Transmission distance (m)	120 ~ 300 *
Gain regulation	Automatic (AGC)
Total weight (g)	183
Consumption (mA)	80 max (Tx) / 200 max (Rx)
Weight (g)	69 (Tx) / 114 (Rx)
Power supply	+12VDC (feeder not supplied)
Dimensions (mm)	45x29x26 (Tx) / 66x45x26 (Rx)
Signalization LED	On (PWR) Signal presence (LINK)
Optical output connector	F-SMA
Electric output connector	BNC (75 Ω)
Storage temperature (°C)	-30 ~ +80
Operating temperature (°C)	-20 ~ +60
Immune to electromagnetic interferences	Yes

NOTES with repeater, FP-REP600 model up to 600 m

OPENING THE BOX

Carefully take the unit and the accessories out from the packaging box. Make sure that the box contains all the components listed in the accessory list.

Carefully check the device and make sure that it was not broken or damaged during transportation.

Do not throw away the box before having checked the unit carefully and made sure it works properly.

LIST OF THE INCLUDED ACCESSORIES:

- 1 User's manual
- 1 Transmitter
- 1 Receiver
- 1 BNC/BNC 75Ω cable

DESCRIPTION

The system converts and transmits, by plastic optical fiber (POF), the analog video signal coming from any camera or video source.

The system is made up of the following:

- a) a transmitting unit that can be interfaced with any analog camera;
- b) a receiving unit to display the image onto a color TV or by means of an acquisition card (optional) on a PC.

The color image in PAL/NTSC standard is acquired from the camera through the transmitting unit and sent via plastic optical fiber to the receiver that can be connected to a color TV or a PC with a frame grabber (not supplied).


FP-TRX150 connection diagram



FP-TRX300 connection diagram



FP-TRX300 and FP-REP600 connection diagram





The use of the FP-REP600 model repeater allows you to reach and transmit up to 600 m

INSTALLATION OF THE DEVICE

The video system installation is very easy and requires a few minutes by using an electrician's common tools. Follow the instructions carefully.


PHASE 1 – THE END OF THE PLASTIC FIBER

The ends of the cable must be carried out according to the following procedure:

	<p>1st Phase: Cut of the fiber The cut can be carried out by any cutting tool</p>
	<p>2nd Phase: Removal of the sheath Remove about 1 cm of sheath The optical cable sheath has a diameter of about 2.2 mm. The optical cable has a diameter of 1.0 mm. ATTENTION The sheath removal can be carried out with a standard stripping tool that has hole dimensions higher than 1.0 mm so that the optical cable will not be damaged.</p>
	<p>3rd Phase: Crimping the connector Insert the FSMA connector on the previously stripped cable up to when the optical cable comes out of about 2 mm. Crimp the FSMA connector on the cable sheath. ATTENTION The FSMA connector cannot be crimped directly on the optical cable. The FSMA connector crimping tool must have a hexagonal diameter of 3 mm. If a FSMA – CRIMP crimping tool is used, use the 0.122 hole.</p>
	<p>4th Phase: cleaning the fiber To eliminate possible micro-lesions caused by the cut of the cable, use 1,000 abrasive paper possibly using the FP-CLEANTOOL. Polish until the fiber does not jut out from the FP-CLEANTOOL. ATTENTION To optimize this process, we recommend making the figure 8 with the connector on the abrasive paper so that the optical cable can be lapped evenly.</p>

PHASE 2: THE DEVICE INSTALLATION

The transmitter: (FP-TRX150 o FP-TRX300)

	<p>Connect the camera output to the transmitter module input with the supplied BNC plug cable. The supplied cable can be replaced by any 75Ω BNC cable (max. length 3 m). Insert the plastic optical fiber (with the F-SMA connector at one end) and fix it, screwing the connector onto the transmitter. Connect the 12V power supply; the connector polarity is shown on the metal surface. The transmitter will signal the correct lighting by means of the proper LED.</p>
---	---

The receiver:


Connect the receiver module output to the monitor/DVR input with a 75Ω BNC plug cable (not supplied – max. length 3 m).

Insert the plastic optical fiber (with the F-SMA connector at one end) and fix it, screwing the connector onto the receiver.

Connect the 12V power supply; the connector polarity is shown on the metal surface.


The receiver will signal the correct lighting by means of the proper LED.

FP-TRX150



Manually adjust the gain (ADJ) with a screwdriver.
 If the image displayed is too bright on the monitor, decrease the receiver gain by turning it clockwise.
 If image displayed is too dark on the monitor, increase the receiver gain by turning it counterclockwise.

FP-TRX300



The receiver provides an automatic regulation of the gain and does not need regulation.
 The LINK indicator shows the correct presence of the video signal with the color green and its absence with the color red.

OTHER ACCESSORIES

The range of Fracarro products includes the following accessories that are useful for installing devices working with plastic optical fiber:



FSMA-ADAPTER
F-SMA metal connectors to crimp (box of 10 pieces)



PAPER-1000
KIT for working on the cable end
(Crimping tool, 1,000 abrasive paper, 10 F-SMA connectors, automatic puck stripping tool, cutter)



FSMA-CRIMP
Crimping tool of F-SMA HEX 3.0 mm connectors

MANUFACTURER'S NOTES

In the presence of an electromagnetic field with a frequency between 1.4 GHz and 2 GHz and a level higher or equal to 3V/m (according to the EN 61000-4-3 variant A1), the FP-TXRX300 device, during its normal operation, allows for the presence of slight video signal interferences of the video signal. These interferences are shown as slightly marked horizontal lines over the image, which is always perfectly visible.

TROUBLESHOOTING**FP-TXRX150:**

- 1) You can't see the image
 - a. double check the electric connections (LED PWR lit on TX and RX) and BNC cables
 - b. check that the transmitter emits a green light from the SMA receptacle
 - c. check that green light comes out from the fiber close to the receiver
 - d. adjust the gain regulator (E) (turn counterclockwise)
- 2) The image is very bright and/or instable
 - a. adjust the gain regulator (E) (turn clockwise)
 - b. check the fiber length (longer than 10 m)
- 3) The image has a poor quality
 - a. adjust the gain regulator (E) (turn counterclockwise)
 - b. check the length of the fiber (less than 150 m)
 - c. review the connectors by using abrasive paper and a puck

FP-TXRX300:

- 1) Passing from light/shade, the TV loses the image
 - a. disconnect the camera AGC
- 2) You can't see the image
 - a. check that the device switches on correctly
 - b. check that the LINK indicator is green
 - b. check the length of the fiber (within the range of 120 m-300 m)
- 3) RED LINK LED/ poor quality of the image
 - a. check the length of the fiber (if less than 300 m, insert a repeater at the half of the tract)
 - b. redo the connection

Fracarro Radioindustrie S.p.A. - Via Cazzaro n.3 - 31033 Castelfranco Veneto (TV) ITALIA Tel: +39 0423 7361 - Fax: +39 0423 736220

Company subjected to the management and coordination of CAMI S.r.l. – V.A.T. number 02399120266

Fracarro France S.A.S. – 7-14 rue du Fossé Blanc - 92230 Gennevilliers Cedex
FRANCE Tel: +33 1 47283400 - Fax: +33 1 47283421

Fracarro Iberica - Polígono Táctica, "Ciudad de los negocios" c/2A nº4 - 46980 Paterna - Valencia - ESPAÑA Tel. +34/961340104 - Fax +34/961340691

Fracarro (UK) - Ltd, Unit A, Ibex House, Keller Close, Kiln Farm, Milton Keynes MK11 3LL UK Tel: +44(0)1908 571571 - Fax: +44(0)1908 571570

Fracarro Tecnologia e Antenas de Televisao Lda - Rua Alexandre Herculano, nº1-1ºB, Edifício Central Park 2795-242 Linda-a-Velha PORTUGAL Tel: + 351214156800 - Fax+ 351214156809

www.fracarro.com info@fracarro.com



FP-TXRX Rev. 0 07th Nov. 2008